


Basic physics

What are the 2 most popular principles to measure temperature?

Resistance Temperature Detector (RTD)



Thermocouples (TC)




Pt100 mean

"Pt" means "Platinum"


"100" means "100 Ohm" at "0°C"


Temperature measurements



Endress+Hauser 🖽

RTD – Resistance Temperature Detector





- An RTD changes its resistance value proportional to the temperature!
- A Pt100 is a "PTC"
 Pt from Platinum, 100 means 100 Ω at 0°C
 Resistance with "Positive Temperature Coefficient"


Reference standard for RTD: EN 60 751


Temperature / Resistance relationship

$$R_{\text{Pt}100} = 100 + (\text{alfa} \times T) - (\text{beta} \times T^2)$$

$$1^{\circ}$$
C = 0.385 Ohm

Jan Heynen






Endress+Hauser 🖽

RTD - 2 wire, 3 wire or 4 wire connection?

2 wire configuration: Transmitter




| Resistances:

 R_{Pt100} +2 R_W

| Error: 2 R_W

< 0,5m

3 wire configuration:



Resistances:


$$(R_{Pt100}+2 R_W)$$

- $(2 R_W) = R_{Pt100}$

| **Error** if wires and terminals are not 100% identical

< 30m

4 wire configuration:



Resistances:

 R_{Pt100}


Error:


No systematical error

< 1000m


RTD - Accuracy


Accuracy according to DIN EN 60751





Measurement via Thermocouple







Jan Heynen

TC – Measuring principle

- **Indirect measurement** of temperature
- The Electromotive Force (EMF) is measured due to a physical effect




TC – Thermocouple - Seebeck Effect



SEEBECK EFFECT


If the conductors' metal is not the same and if the two junctions are at different temperatures, between them a voltage (EMF) is generated, and hence an electric current flows in the circuit.

TC - Useful ranges




TC - Accuracy

- Tolerance classes according to IEC 584
- Class 1Special
- Class 2 Standard



Jan Heynen



Endress+Hauser 🖽

Jan Heynen

Where to use TC?

- High temperatures (300°C 1700°C)
- High vibration
- Fast response times
- Mechanical stress

E+H Temperature

The Thermometer




Modular Thermometers for general applications

- Solutions for different branches
- Measuring principles: RTDs and TCs
- Replaceable Inserts
- Main applications: Chemical industries ...






Assembling examples



Installation for general purpose industrial applications

Endress+Hauser 🖽


Thermometer for existing TW's




Endress+Hauser 🖽

Slide 21

Set-up of the temperature assemblies




Compact thermometers





Temperature Transmitters



	Foundation Fieldbus	ProfiBus	ProfiNet
TMT162	TMT162	TMT162	-
TMT82	TMT85	TMT84	TMT86
TMT82	-	-	-
TMT82	TMT85	TMT84	TMT86
2-ch universal	2-ch universal	2-ch universal	2-ch universal
	Ex	Ex	Ex
SIL 2 SC 3	-	•	Ethernet-APL
	TMT82 TMT82 TMT82 TMT82 Z-ch universal	TMT82 TMT82 TMT85 TMT85 TMT85 TMT85 TMT85 Ex	TMT82 TMT82 TMT82 TMT85 TMT84 TMT82 TMT85 TMT84 TMT84 TMT84 TMT82 TMT85 TMT84 Ex Ex

Endress+Hauser 🖽

Device Features – TMT8x transmitters











Supply voltage: 9 - 32 V DC

Galvanic isolation: 2 kV (Fieldbus/inputs)

Measurement accuracy: 0.1 K

Compatible with the display TID10









iTEMP TMT82 -



SIL2/SIL3 Transmitter










System integration		
Endress+Hauser	FieldCare (FDT/DTM)	
Siemens	SIMATIC PDM (EDD)	
Emerson	AMS; FC375/475	

TMT82


2 Sensor inputs
High accuracy (0.1 K Pt100)
SIL acc. IEC61508 (SIL2, SW SIL3)
HART6 Protocol
Advanced diagnosis functions
NE107/VDE2650 conformity
Display compatibility (TID10)
International approvals


Design





Thermowells







Thermowell calculation tool

The "Sizing Thermowell Tool" can be found on the Endress+Hauser website for online calculation and engineering of all Endress+Hauser thermometer thermowells.


Why Thermowells?

- Advantages
- Sensor can be replaced during operation
 - Calibration
 - Replacement
- Standard Sensor can be adapted to many different applications:
 - Thickness (Pressure attack)
 - Material (Chemicals attack)
 - Shape (Flow attack)
 - Process connection (Flange, thread, weld-in)
- Disadvantages
- Longer response time to temperature changes



Stresses to withstand

- Difference between inner and outer pressure
- Pressure coming from flowing medium
- Stresses due to own weight
- Pressure surges (e.g. water hammer)
- Loading by vibration through periodic vortexes (Kármán-turbulances)
- Material and internal stresses ...





Thermowell – Important differences

Bar stock thermowell



Pipe thermowell




Bar stock thermowells - versions



Endress+Hauser 🖽

Pipe thermowells - versions





Endress+Hauser 🖾

Cost reduction with Quickneck® – Quicksens® - Strongsens®



Sensor technology






Endress+Hauser 🖽

Cost reduction by Quicksens®

- Thin film element with optimized thermal contact
- New production method granting for highest quality



Endress + Hauser 🔣

Cost reduction by Strongsens®

novel inserts with unmatched robustness

Vibration resistance higher than 60g

- → Greater system safety due to lower risk of failure
- → Reduction of life cycle costs due to longer life-time

Automated production


- → Full traceability and best quality
- → Highest process safety

High long-term stability

- → Reliable measurement values
- → High system safety



Thermometer product overview (1)




Thermometer product overview (2)





iTherm TrustSens TM371







https://www.youtube.com/watch?v=zKxuQNABWQI&t=26s




Manual calibration of thermometers in retrospect




Endress+Hauser 🖽



Endress+Hauser 🖽











Jan Heynen




People for Process Automation!

Innovative solutions for higher productivity, safety and plant availability




Endress+Hauser 🖽

First Step – Evolution with iTHERM QuickNeck




First Step – Evolution with iTHERM QuickNeck






Inline calibration with iTHERM TrustSens




Endress+Hauser 🖽


Curie Temperature as calibration reference





Curie Temperature as calibration reference





Automatic calibration certificate

Endress+Hauser FieldCare software





The revolution of calibrations – iTHERM TrustSens




The past

The revolution of calibrations – iTHERM TrustSens












The revolution of calibrations – iTHERM TrustSens



The future!




The Revolution - iTHERM TrustSens

100% Compliance – 0% Effort





Special Application examples






Temperature Engineered Solutions (TES)








Engineered solutions – Example: Straight Multipoint



Endress+Hauser 🖽

Product offering / Segmentation- Multipoints



Endress + Hauser 🖽

Product features and the values for the customer





iTHERM TMS01 MultiSens Flex Multipoint Modular direct contact TC and RTD multipoint thermometer for Oil&Gas and Petrochemical applications

MultiSens Flex benefits

- Infinite 3D sensors distribution layouts for any process monitoring configuration
- High degree of customization thanks to a modular product design for easy installation, process integration and maintenance
- High degree of insert process compatibility as per standard IEC 60584, ASTM E230 and IEC 60751
- On board electronic heat protection for long product lifetime
- Compliance to different types of protection for use in hazardous locations for a wide and easy process integration

By complying with the highest safety standards, it provides a complete temperature profile just by using one nozzle. The TMS01 is configurable with or w/o thermowells for an optimal response times or mechanical strength/sensors replacement.

Product offering – iTHERM MultiSens Flex – TMS01

Frame/neck

- Modular support system, adjustable for all available junction boxes
- Support frame: Material: 316/316L
- Tube neck: 304

Process connection

- Flanges according to ASME and EN standards available
- Other connections on requests
- Material: 316/L; 304/L; 316Ti; 321; 347

Thermowells (optional)


- Tube according to EN/ASME standards
- Material: 316/L; 321; 347

Junction Box

Marking:

- Atex II 2 GD Ex e IIC Gb
- Atex Ex ia Ga IIC T
- Atex tb IIIC

Material: AISI 316, Aluminum (on reguest)



Electronics

- TMT 8x, 18x, 125
- Terminal blocks

Inserts

- Thermocouple (type J,K,N,T) grounded and ungrounded execution
- RTD Pt100 Wire Wound, Thin film or StrongSens
- Insert sheath material: Alloy600,
 316/L, Pyrosil or special on request
- Ø range = from 2 mm (0.08 in) to 6 mm (0,23 in)
- Single or duplex thermocouples

Endress+Hauser 🖽

Slide 63 08/30/2024

Product features and the values for the customer



iTHERM TMS02 MultiSens Flex Multipoint
Modular direct contact TC and RTD multipoint thermometer for
Oil&Gas and Petrochemical applications
MultiSens Flex benefits

- Same as TMS01
- Increased safety thanks to a diagnostic chamber able to contain the process in the event of leakages through the primary seals

Product offering – iTHERM MultiSens Flex – TMS02

Frame/neck

- Modular support system, adjustable for all available junction boxes
- Material: 316/316L

Process connection

- Flanges according to ASME and EN standards available
- Other connections on requests
- Material: 316/L; 304/L; 316Ti; 321; 347


Thermowells (optional)

- Tube according to EN/ASME standards
- Material: 316/L; 321; 347


Junction Box

Marking:

- Atex II 2 GD Ex e IIC Gb
- Atex II 2 GD Exd IIC Gb
- Atex Ex ia Ga IIC T



Aluminum (on request)



Electronics

- TMT 8x, 18x, 125
- Terminal blocks

Diagnostic Chamber

- Integrated on board
- Materials as for the Process connection


Inserts

- Thermocouple (type J,K,N,T) grounded and ungrounded execution
- RTD Pt100 Wire Wound, Thin film or StrongSens
- Insert sheath material: Alloy600, 316/L, Pyrosil or special on request
- Ø range = from 2 mm (0.08 in) to 6 mm (0,23 in)
- Single or duplex thermocouples



Slide 65 08/30/2024

Product offering – iTHERM MultiSens Flex – TMS0x





Product features and the values for the customer





iTHERM TMS21 MultiSens Slim Multipoint Minimally invasive bendable TC multipoint thermometer for Petrochemical and Chemical applications

It is composed of several low diameters thermocouples protected by one overall primary tube thermowell. Two different product configurations are available, with or without flexible upper thermowell-hose (for axial centering).

MultiSens Slim benefits

- High number of measuring points in a small diameter
- Low invasiveness temperature profiling probe
- Easy mounting and cabling

It can monitor the temperature on a <u>very high number of points</u> along a line just by using one process connection.

Product offering – iTHERM MultiSens Slim – TMS21

Frame/neck

- As accessory
- Material: 316/316L

Process connection

- Compression fitting (SS 316L)
- Other connection types on requests

Thermowells

- Tube according to EN/ASME standards
- Material: 316/L; 321; 347
- 3.2 mm (0.13 in); 6 mm (0.24 in)
- 6.35 mm (0.25 in); 8 mm (0.31 in)
- 9.5 mm (0.37 in); special on request

Extension Conduit

- Used to protect the extension cables from environmental agents
- Mat.: Polyamide; other materials on request
- IP66/67 degree by using E+H suggested adapters.


Electronics

- As accessories
 - TMT 8x, 18x, 12x 125

Inserts

Not replaceable grounded or ungrounded thermocouple inserts

- Thermocouple (type J,K,E,N)
- Insert sheath material: Alloy600, 316/L, or special on request
- Ø range = from 0,5 mm (0.019 in) to1,5 mm (0,06 in)



Product features and the values for the customer



iTHERM TMS11 MultiSens Linear Multipoint Modular straight TC and RTD multipoint thermometer for Oil&Gas and Petrochemical applications

MultiSens Linear benefits

- High degree of insert process compatibility as per standard IEC 60584, ASTM E230 and IEC 60751
- Several safety standard compliances (such as but not limited to ATEX, PED) for easy process integration
- High degree of customization thanks to a modular product design for easy installation, process integration and maintenance
- On board electronic heat protection for long product lifetime
- Superior mechanical strength and sensors replacement thanks to a primary thermowell



The TMS11 is available with a primary thermowell for <u>superior</u> mechanical strength/sensors replacement.

Product offering – iTHERM MultiSens Linear – TMS11

Frame/neck

- Modular support system, adjustable for all available junction boxes
- Support frame: Material: 316/316L
- Tube neck: 304

Process connection

- Flanges according to ASME and EN standards available
- Other connections on requests


Thermowell

- Tube according to EN/ASME standards
- Material: 316/L; 321; 310S
- Sizes:
- 1/2; 3/4; 1; 1 1/4; 1 ½; 2; 2 ½; 3 Inches
- **21.3**; 26,7; 33,4; 42,2; 48,3; 60,3; 73; 88.9 mm

Junction box

Marking:

- Atex II 2 GD Ex e IIC Gb
- Atex Ex ia Ga IIC T / Atex tb IIIC
- Material: AISI 316, Aluminum (on request)




Electronics

- TMT 8x, 18x, 125
- Terminal blocks

Inserts

- Thermocouple (type J,K,N,T) grounded and ungrounded execution
- RTD Pt100 Wire Wound, Thin film or StrongSens
- Insert sheath material: Alloy600, 316/L, Pyrosil or special on request
- $\emptyset = 3 \text{ mm } (0.12 \text{ in})$
- Single or duplex thermocouples



Slide 70 08/30/2024

Product features and the values for the customer



iTHERM TMS12 MultiSens Linear Multipoint Modular straight TC and RTD multipoint thermometer for Oil&Gas and Petrochemical applications

MultiSens Linear benefits

- Same as TMS11
- Increased safety thanks to a diagnostic chamber able to contain the process in the event of leakages through the primary seals

Product offering – iTHERM MultiSens Linear – TMS12

Frame/neck Mat: 316L • Size compatible with diagnostic chamber

Process connection

- Flanges (Welding neck) according to ASME and EN standards available
- Other connections on requests

Thermowell

- Tube according to EN/ASME standards
- Material: SS 316/L; 321;
- 1/2;3/4;1;1 1/4;1 1/2,2,2 1/2,3 Inches
- **2**1.3;26,7;33,4;42,2;48,3,60,3;73;88,9 mm

Junction box Marking: Atex II 2 GD Ex e IIC Gb Atex II 2 GD Exd IIC Gb Atex Ex ia Ga IIC T Atex tb IIIC Material: AISI 316; Aluminum (on request)

Electronics

tbd

Diagnostic Chamber

- Mat: 316L: 321
- Size:
- 1 ¼; 11/2, 2, 2 1/2, 3 inches - 42,2; 48,3, 60,3; 73; 88,9 mm

Inserts

- Thermocouple (type J,K,N,T) grounded and ungrounded execution
- RTD Pt100 Wire Wound, Thin film or StrongSens
- Insert sheath material: Alloy600, 316/L, Pyrosil or special on request
- $\emptyset = 3 \text{ mm } (0.12 \text{ in})$
- Single or duplex thermocouples

Endress + Hauser 431

Slide 72 08/30/2024

Product features and the values for the customer



iTHERM TMS31 MultiSens Bundle Multipoint High precision multipoint thermometer for average and local temperature measurement in silos and storage applications

It can monitor the temperature on a high number of points along a line just by using one entry. This TMS31 is composed of several TCs or RTDs fixed to a primary metal rope or inside a customized polymeric conduit.

MultiSens Bundle benefits

- Mechanically flexible and high number of measuring points probe, mounted on rope/rod;
- Not affected by pressure conditions
- Easy mounting and cabling, installation versatility

Specially designed for <u>temperature average detection</u> and <u>temperature</u> <u>profiling</u> in silos and storage applications.



Product offering - iTHERM MultiSens Bundle - TMS31

Frame/neck

Tube neck

Process connection

- Flanges according to ASME and EN standards available
- Other connections on requests

Reinforcement system


- Metallic Rope + balance weight
- Polymeric flexible hose

Junction box

Marking:

- Atex II 2 GD Ex e IIC Gb
- Atex Ex ia Ga IIC T / Atex tb IIIC

Material: AISI 316, Aluminum (on request)




Electronics


tbd

Inserts

- Thermocouple (type J,K,N,T) grounded and ungrounded execution
- RTD Pt100 Wire Wound, Thin film or StrongSens
- Insert sheath material: Alloy600, 316/L, Pyrosil or special on request
- \emptyset = from 1,5 to 3 mm (0,12 in)
- Single or duplex thermocouples




Surface temperature measurement






Surface temperature measurement


Fixed style connection



Fan Tip





Pad Tip




Knife-edge Tip

Removable connection







Washer Pad

High Temperature with leak detection




Definition:

Customized products for harsh applications, e.g. gasifiers, able to withstand at very high temperatures, sometimes in combination with pressure, and very aggressive environments.

Features:


- Increased safety Purging system
- Special process connections are available
- Special thermowell materials are needed

High Temperature with leak detection





High Temperature with leak detection





Questions?



